



1831 Fort Union Blvd, Salt Lake City, Utah 84121
800-347-6439 • 801-943-7277
www.companioncorp.com

USB Camera

Packing List

Thank you for purchasing COMPanion's USB Camera. This package should contain the following items. If any are missing or damaged, please call COMPanion at 1-800-347-6439 or 1-801-943-7277.

This packing list is used for the Indicated product(s):

- Camera, USB Interface, Mac & Windows—V6458

Your package should contain the following:

- Camera with attached USB Cable
- USB Camera Installation Guide
- COMPanion Camera Exchange and Warranty Repair Policy

Inspected by: _____ On: _____



1831 Fort Union Blvd, Salt Lake City, Utah 84121

800-347-6439 • 801-943-7277

www.companioncorp.com

USB Camera


Installation Guide

Thank you for purchasing COMPanion's USB Camera.

To begin, connect the USB Camera's cable to an open USB port on your computer. Next, you will need to make sure that you have Adobe Flash

Player installed. This can be installed by visiting <http://get.adobe.com/flashplayer/> in your web browser. Now that you have Adobe Flash Player installed, you need to allow access to the USB Camera in KeepnTrack.

Log into the KeepnTrack **Kiosk** or **Self Service Station** on the machine with the camera and open **Workstation Management** from the link at the bottom of the window or in the actions menu in the upper left corner (Image 1).



For Technical Support please call 1.800.320.5830 or [click here](#) to email Technical Support.
Click here to order KeepnTrack supplies - [Workstation Management](#)




Image 1

Within Workstation Management, click on the **Scanners and Cameras** button in the lower left and put a check in the box titled **Look for Camera** (Image 2).




Image 2

Clicking the **Activate Camera** button will open the Camera Photo Capture Window. **Option click** or **right click** on the Adobe Flash Player Settings dialog and select **Settings** from the menu (Image 3).




Image 3

On the Settings dialog, click the **Privacy** tab and select the **Allow** and **Remember** options (Image 4).




Image 4

Now click on the **Camera** tab and select **Logitech Camera** from the menu and click **Close** (Image 5).




Image 5

Your USB Camera is now set up and ready to be used any time you need to capture a picture in KeepnTrack.

Please contact COMPanion Customer Support by phone at 1-800-347-4942 or by email at support@companioncorp.com if you have any questions or require assistance.



1831 Fort Union Blvd, Salt Lake City, Utah 84121

800-347-6439 • 801-943-7277

www.companioncorp.com

Hardware Warranty

COMPanion Corporation's Scanners, Printers, Cash Drawers, and other hardware devices are warranted by COMPanion against defects in materials and workmanship for the specified period from the date of shipment by COMPanion to the end-user. During this warranty period, we, or our designated repair facility, will repair or replace (at our option) at no charge any device that proves to be defective, provided you return the device, shipping prepaid, to COMPanion, following the return guidelines below.

Your Standard Warranty Period: 1 Year

This warranty does not apply if the product has been damaged by accident or misuse or as the result of service or modification by other than COMPanion or our designated repair facility.

No other express warranty is given. The replacement of the device is your exclusive remedy. Any other implied warranty of merchantability or fitness is limited to the duration of this written warranty. Some states, provinces and countries do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you.

In no event shall COMPanion or its designated repair facility be liable for consequential damages. Some states, provinces, and countries do not allow for the exclusion or limitation of incidental or consequential damages, and so the above limitations or exclusions may not apply to you.

Return Guidelines:

Should your device fail to work during the period of this warranty, contact COMPanion Customer Support at 1-800-347-4942. Our staff will help resolve the issue or provide return instructions.

Should your device still fail to operate after a reasonable period of trouble-shooting, your COMPanion support technician will issue a Return Merchandise Authorization (RMA) number and provide information about how to properly return the device to COMPanion.