

# KeepnTrack HD Camera

## Packing List

Thank you for purchasing the KeepnTrack HD Camera. This package contains the items listed below. If anything is missing or damaged, please call us toll-free at 1-800-347-6439.

### **This packing list is used for the following product(s):**

- KeepnTrack HD Camera (V6458)


### **Your package contains the following:**


- KeepnTrack HD Camera
- Installation Guide
- Warranty Information

# KeepnTrack HD Camera

## Installation Guide

Thank you for purchasing the KeepnTrack HD Camera. Follow these steps to set up the camera on your workstation:

1. Connect the USB cable to your computer. The drivers will be installed automatically.
2. Log in to a KeepnTrack kiosk on the computer to which the camera is attached.
3. Navigate to the Actions  menu and select Workstation Management.
4. On the left, click the **Scanners and Cameras** icon. On the right side under **Camera**, check the **Look for Camera** box.
5. Click **Activate Camera** to open the capture window. When your browser asks to access the camera, choose Allow.



If the webcam isn't working properly, check your browser settings to make sure camera access is allowed for your KeepnTrack site, or try a different browser.

All done! Your KeepnTrack HD Camera is now set up and ready to be used any time you need to capture a picture in KeepnTrack.

# Hardware Warranty

COMPanion Corporation's scanners, printers, cash drawers, and other hardware devices are warranted by COMPanion against defects in materials and workmanship for the specified period from the date of shipment by COMPanion to the end-user. During this warranty period, we, or our designated repair facility, will repair or replace (at our option) at no charge any device that proves to be defective, provided you return the device, shipping prepaid, to COMPanion, following the return guidelines below.

## **Standard Warranty Period: 12 Months**

This warranty does not apply to damage caused by accident or misuse, including by the use of paper not sourced from COMPanion, or as the result of service or modification by other than COMPanion or our designated repair facility.

No other express warranty is given. The replacement of the device is your exclusive remedy. Any other implied warranty of merchantability or fitness is limited to the duration of this written warranty. Some states, provinces, and countries do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you.

In no event shall COMPanion or its designated repair facility be liable for consequential damages. Some states, provinces, and countries do not allow for the exclusion or limitation of incidental or consequential damages, and so the above limitations or exclusions may not apply to you.

## **Return Guidelines**

Should your device fail to operate during the period of this warranty, contact COMPanion Customer Support at 1-800-347-4942. Our staff will help resolve the issue or provide instructions to properly return the device to COMPanion.